

The Original  
**Balloon  
GIZMO**


**JUMBO 36" IN-GROUND SYSTEM**  
**ASSEMBLY INSTRUCTIONS**



**35026**  
Jumbo In-Ground System

0 91451 35026 4


Balloon Sold Separately





# JUMBO 36" IN-GROUND SYSTEM (#35026) ASSEMBLY INSTRUCTIONS

## PARTS LIST



## TOOLS & TIPS

**Air Inflator** (sold separately)  
Our High Power Inflator (#35057) is the perfect solution for your inflation needs.  
**Inflates balloons in seconds!**

**Rubber Mallet** (not included)  
We recommend using a rubber mallet to drive the stake into the ground. A regular hammer will cause excessive wear and damage over time.

1. Make sure you have the necessary parts and tools before beginning.  
*NOTE: Requires one Jumbo Balloon Gizmo™ balloon (sold separately).*

2. Do NOT inflate balloon until Step 10.

3. Locate the channel hole in the pocket on the bottom of the **Balloon Gizmo™ Jumbo Balloon (A)**. Use an air inflator to blow air into the channel (photo 1).  
*NOTE: This will not inflate the balloon, but will help loosen the interior channel of the balloon for Step 4.*

4. Insert the **Stabilizing Rod (B)** (rubber tipped end first) through the entire channel in the center of the balloon.  
*NOTE: The rod will NOT protrude from the top of the balloon.*

5. Insert the first half of the **Jumbo Connector Clip (C)** (with the threaded post) into the pocket on the balloon. Slide the end of the stabilizing rod through the hollow center of the threaded post (photo 2).

6. Fold the balloon flaps over the threaded post of the connector clip making sure to align the pegs with the openings in the flaps (photo 3).

7. Lay the second half of the jumbo connector clip onto the first half. The holes and pegs of each half will align when properly seated. *NOTE: Clip will be loose until it is attached to the jumbo rod.*

8. Attach the **Standard Connector Clip (D)** to the **Jumbo Rod with Spike (E)** by aligning the teeth on the connector clip with the square slots on the cup of the jumbo rod. Push the pieces together until they click (photo 4).

## PHOTO 1



## PHOTO 2



## PHOTO 3



## PHOTO 4




**CONTINUED ON  
NEXT PAGE**

# Balloon Gizmo™

## JUMBO 36" IN-GROUND SYSTEM (#35026) ASSEMBLY INSTRUCTIONS

### PARTS LIST



### TOOLS & TIPS

**Air Inflator** (sold separately)  
Our High Power Inflator (#35057) is the perfect solution for your inflation needs.  
**Inflates balloons in seconds!**

**Rubber Mallet** (not included)  
We recommend using a rubber mallet to drive the stake into the ground. A regular hammer will cause excessive wear and damage over time.

9. Attach **Jumbo Rod with Spike (E)** to the balloon by screwing the post of the jumbo connector clip into the threaded end on the jumbo rod. Continue until tight and the locking button on the jumbo connector clip is seated in one of the notches on the standard connector clip (photo 5).

10. Inflate the balloon using an air inflator until the surface is smooth and wrinkle free. *NOTE: Slightly under-inflate in hot climates to allow space for air to expand.*

11. Attach **Metal Spike (F)** onto the **Jumbo Pole (G)** by screwing the spike into the threaded end of the pole.

12. Anchor the jumbo pole in your desired location by pushing the metal spike into the ground until the spike is no longer visible.\*

13. Loosen the wingnut on the top of the jumbo pole. Attach the jumbo balloon by inserting the spiked end of the jumbo rod into the opening on top of the pole. Secure in place by re-tightening the wingnut (photo 6).

### PHOTO 5



### PHOTO 6



\*Certain settings may require additional items (sold separately) to properly install and display Balloon Gizmo™ systems. See below for information.

### VERSATILE SOLUTIONS FOR EVERY INSTALLATION

#### Indoor & Hard Surface Installation



Balloon Gizmo™  
Water Base  
#35066

For displaying indoors or on a hard surface, omit Steps 11-12. Instead, place the water base in your desired location and fill with water. Insert the jumbo pole (threaded side down) through the hole in the top of the base and proceed to Step 13.

#### Loose Soil Installation



Balloon Gizmo™  
Jumbo Ground Stake  
#35067

For displaying in locations with loose or sandy soil, drive the stake into the ground using a rubber mallet. Omit Step 12. Insert the metal spike and pole into the open hole on top of the ground stake. Tighten the wingnut to secure the pole in place.