# The Original

# ASSEMBLY INSTRUCTIONS



Balloons Sold Separately





# 17" IN-GROUND BOUQUET SYSTEM (#35037) ASSEMBLY INSTRUCTIONS





- Make sure you have the necessary parts & tools before beginning. NOTE: Requires four 17" Balloon Gizmo™ balloons (sold separately).
- BEFORE INFLATING THE BALLOONS, insert a **Standard Connector Clip (B)** into the pocket located on the bottom of each **Balloon Gizmo™ Balloon (A)**.
- 3. Fold the balloon flaps over the connector clips to secure them in place (photo 1).
- 4. Attach a balloon to each **Standard Rod** (C) and to the **Jumbo Rod with Spike** (D) by aligning the square slots on the cup end of each rod with the teeth on the connector clip. Push pieces together until they click (photo 2).
- Inflate each balloon until the surface is smooth and wrinkle free. NOTE: Slightly under-inflate in hot climates to allow space for air to expand.
- 6. Drive **Jumbo Ground Stake (E)** into the ground in your desired location using a rubber mallet. Make sure to insert the stake up to the collar for maximum stability.\*
- 7. Fasten **Metal Spike (F)** onto **Jumbo Pole (G)** by screwing the spike into the threaded end of the pole (photo 3).
- 8. Insert the metal spike and pole into the hole on top of the ground stake. Tighten the wingnut on the ground stake to secure the pole in place. (photo 4).

### CONTINUED ON NEXT PAGE

\* If you are planning to display indoors or on a hard surface, omit Steps 6 through 9. Instead, place the water base in your desired location and fill with water. Insert the jumbo pole (threaded side down) through the hole in the top of the base and proceed to Step 10.









### **TOOLS & TIPS**

Air Inflator (sold separately)
Our High Power Inflator (#35057) is the perfect solution for your inflation needs.
Inflates balloons in seconds!

**Rubber Mallet** (not included)
We recommend using a rubber mallet to drive the stake into the ground. A regular hammer will cause excessive wear and damage over time.






# 17" IN-GROUND BOUQUET SYSTEM (#35037) ASSEMBLY INSTRUCTIONS




 Remove the wingnut from the top of the pole. Slide the EMPTY Water Base (H) down the pole and fill the base with water (photo 5). NOTE: For more permanent installation, the base can also be filled with sand.

If adding **Bouquet Upgrade Kit #35082** (sold separately), follow the instructions included with that kit from this point on, otherwise, continue to Step 10.

- 10. Loosen the clamps on **Bouquet Bracket (I)** and slide it onto the jumbo pole. *NOTE: To slide the bracket, grip the arms on either side of the clamps, pull them slightly apart, and move the bracket into place* (photo 6).
- 11. Insert the spiked end of the assembled jumbo rod and balloon into the opening on top of the jumbo pole. Secure in place by re-screwing the wingnut into the threaded hole (photo 7).
- 12. Attach the three fully assembled standard rods to the bracket by aligning the locking peg on each rod with the slotted holes on the bracket. Slide each rod in and twist a ¼ turn counterclockwise to lock in place (photo 8).
- 13. Adjust the final vertical position of the bouquet bracket assembly and secure it in place by relocking the clamps. NOTE: When properly assembled, the lower layer of balloons will lightly touch the bottom of the center balloon.









### **TOOLS & TIPS**

Air Inflator (sold separately)
Our High Power Inflator (#35057) is the perfect solution for your inflation needs.
Inflates balloons in seconds!

**Rubber Mallet** (not included)
We recommend using a rubber mallet to drive the stake into the ground. A regular hammer will cause excessive wear and damage over time.



