

# **Foil Centerpiece Kit**

For Use with Air-Filled Balloons



Tabletop centerpiece kits are the perfect alternatives to helium bouquets.

Simply air-inflate your balloons and attach to the cups to create beautiful centerpieces for any event.

- Easy to assemble
- Transparent sticks and base
- Fill base with water
- Reusable
- 10 Kits per case

BIRTHDAY

New!
Foil Air-Fill
Centerpiece Kit
#1563 • 10 pk
10 pk
12"W x 25"H
Holds 7 air-filled foil balloons.
Balloons sold separately.









# Foil Centerpiece Kit

### Assembly Instructions

# **Supplies**

QTY	DESCRIPTION
1	Any Foil Shape Balloon
6	Any Standard Foil Balloons
1	Foil Tabletop Centerpiece Kit #1563
	Hand Pump









**Hand Air** Inflator #1992















800-735-3528 ©2019 Balloons Are Everywhere, Inc. All rights reserved.



Attach MultiTape<sup>™</sup> to all MaxiBases<sup>™</sup>.

### STEP 2

Fill MultiBase<sup>™</sup> with water and screw on cap. Attach MaxiBases<sup>™</sup> to the indented spots on the MultiBase™ and one on the cap.

### STEP 3

Air inflate the foil balloons using a hand pump

Pull balloon neck through slot, wrap neck around base of cup and secure using the Slot-N-Lock™.

Tuck in remainder of balloon neck.

### STEP 4

Place shape balloon on 20" MaxiStick® and standard balloons on the 16" MaxiSticks°.

Insert sticks into base.





Phone 800-239-2000





# Latex Centerpiece Kit

### Assembly Instructions

# **Supplies**

QTY	DESCRIPTION
1	Any Foil Balloon (Standard size or larger)
6	Any 11" Latex Balloons
1	Latex Tabletop Centerpiece Kit #1560
	Hand Pump

#### Latex Centerpiece Kit Includes:





Water Base



Adhesive Tabs

Sticks

















800-735-3528 ©2019 Balloons Are Everywhere, Inc. All rights reserved.



### STEP 2

Fill MultiBase<sup>™</sup> with water and screw on cap. Attach MaxiBases<sup>™</sup> to the indented spots on the MultiBase™ and one on the cap.

### STEP 3

Air inflate foil and latex balloons using a hand pump.

Attach foil balloon to MaxiCup® and latex balloons to standard mylar cups.

Pull balloon neck through slot, wrap neck around base of cup and secure using the Slot-N-Lock™.

Tuck in remainder of balloon neck.

### STEP 4

Place foil balloon on 20" MaxiStick® and latex balloons on the 16" sticks.

Insert sticks into base.





Phone 800-239-2000